



550 S. Green St
Nazareth Pa 18064
Ph 610 759-0320 Fax 610 759-0323

Directions for Installing *Banrite* Chalkboards & *Bancork* Bulletin Boards

1. Start angles 6" from each end of board, spacing other angles equal distance apart. Use same number of angles on top and bottom of board. Example: Board 4' x 8', use 8 angles - 4 on top and 4 on bottom. Number of angles supplied equal length of board.
2. Level bottom angles and fasten with nylon masonry anchors and rawlplugs. Use 3/16" Masonry Drill for masonry walls to insert nylon masonry anchors.
3. Set board on bottom angles to get location of top angles. Remove board and fasten top angles to wall.
4. Boards 4' x 6' or larger spot Banco Mastic Cement to either the wall or back of board approximately every 16". Use enough Mastic that when the board is compressed the spots will be 4" or 6" in diameter.
5. Set board in place and drill 9/64" hole in the frame and fasten with No. 8 x 1/2 Phillips Head Self-Tapping Screws.

